



Philips 5000 Series Sandwich Maker

HD2350/80

- Indicator lights show when it's ready to start
- Avoids mess with cut-and-seal plates
- Space-saving vertical storage
- Includes waffle and panini plates
- On/off switch for safety and control

Make quick and easy sandwiches

Sandwich maker for toast, waffles & paninis

- 3 sets of plates for paninis, waffles, and sandwiches
- 750W of power toasts your sandwiches to perfection
- Removable non-stick plates for easy clean-up
- Even heating for perfect melting and toasting
- On/off switch for safety and control
- Compact vertical storage saves space in your kitchen
- Indicator lights display when it's ready to toast
- Built-in cord storage for a tidy countertop
- Easy Lock system snaps shut for a tight seal
- Cut-and-seal plates keep your fillings inside

Indicator lights show when it's ready to start, Avoids mess with cut-and-seal plates, Space-saving vertical storage, Includes waffle and panini plates, On/off switch for safety and control

HD2350/80

Highlights

3 different plate sets



No more sandwiches sticking to plates or endless scrubbing. With our sandwich maker with removable plates, simply take them out and clean easily thanks to the long-lasting non-stick coating.

750 W of power



Rapid heating toasts everything to crisp, golden perfection in this powerful 750W sandwich toaster.

Removable non-stick plates



No more sticking and scrubbing. Simply remove the plates and clean with ease thanks to the long-lasting non-stick coating.

Even heating



Enjoy sandwiches just how you like them: melted, mouthwatering and perfectly golden brown all over.

On/off switch



No need to unplug your sandwich press to turn it on and off.

Compact vertical storage



The sandwich toaster stands vertically for convenient storage on your countertop or in the cupboard.

Indicator lights



Lights clearly indicate when your panini maker is warming up and when it's ready to use.

Built-in cord storage



Wrap the cord for orderly storage without cluttering your kitchen.

Easy Lock system



Press sandwiches to perfection every time with a toastie maker that easily snaps open and closed.

Indicator lights show when it's ready to start, Avoids mess with cut-and-seal plates, Space-saving vertical storage, Includes waffle and panini plates, On/off switch for safety and control

HD2350/80

Specifications

General Specification

Primary Material: PF
Pre-programmed settings: No
Functions: Bake
Product Type: Sandwich maker
Capacity Water tank: N/A
Non-slip feet: No
Cord length: 0.7 m
Cord storage: Yes
Interface: On/off switch
Integrated on/off switch: Yes
Power light: Yes
BPA free: Yes
Warranty: 2 years
Interchangeable plates: Yes
Dishwasher safe: No

Technical Specifications

Power: 750 W
Voltage: 220-240 V
Frequency: 50-60 Hz
Number in pack: 1
Battery Product: No

Compatibility

Included Accessories 1: Waffle plates
Included Accessories 2: Panini plates

Weight and Dimensions

Product Length: 23.9 cm
Product Width: 23.6 cm
Product Height: 11 cm
Product Weight: 2404 g
Package Length: 18.3 cm
Package Width: 26.3 cm
Package Height: 29.4 cm
Package Weight: 643 g

Durability

Case: 100% recycled content
User Manual: 85% recycled paper

Country of Origin

Produced In: China

Safety feature

Automatic shut-off: No



Publication Date
2025-09-06
Version: 56.56.1
EAN: 8720389032820
www.phillips.com

2025 © Versuni Holding B.V. All rights reserved.
PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.