

FR-6964

Multi Crispy Fryer Oven

10 L capacity - 1800 W

Bake fries, vegetables, pie, bread and much more with this Multi Crispy Fryer Oven. Use one of the 10 pre-programmed settings and keep an eye on your food through the window. Including frying basket, 2 grill racks, handle and crumb tray.

Volume	10
Control panel	Digital
Metal inner cavity	Yes
Number of programs	10
Temperature range	70-200 °C
Timer function range	0-24 h
High speed air convection	Yes
Dehydrating function	Yes
Overheat protection	Yes
Number of grill racks	2
Removable crumb tray	Yes
Fryer basket with handle	Yes
Handle	Yes
Non-slip feet	Yes
Power	1800 W







