


Manual ID


2025M-00067

EVERLUXE™ NOODLE CHAIR MANUAL




92 cm x 66 cm x 20 cm / 36 in. x
26 in. x 8 in.

43908




1.22 m x 65 cm x 15 cm / 48 in. x
25 in. x 6 in.

43909



1.83 m x 90 cm x 20 cm / 72 in. x
35 in. x 8 in.

43913



A. WARNING

B. MANDATORY

1. NO PROTECTION AGAINST DROWNING

2. REFER TO INSTRUCTION MANUAL/BOOKLET

3. SWIMMERS ONLY

- 4. KEEP CHILDREN UNDER SUPERVISION IN THE AQUATIC ENVIRONMENT
- 5. THE SUGGESTED AGE OF USER, APPLY ONLY TO CHILDREN ABOVE 14 YEARS OF AGE
- 6. NUMBER OF USERS, 1 ADULT
- 7. MAXIMUM LOAD CAPACITY ... KG
- 8. POOL USE ONLY
- 9. DEVICE REQUIRES BALANCING

For detailed information please refer to the following table:

Item No.	Symbol No.									
	A B	1	2	3	4	5	6	7	8	9
43908; 43909	√	√	√	√	√	√	√	100	√	√
43913	√	√	√	√	√	√	√	140	√	√

OWNER’S MANUAL

WARNING

Non-compliance with these operating instructions may expose you to serious danger.

- **ATTENTION! NO PROTECTION AGAINST DROWNING!**
- **SWIMMERS ONLY!**
- Evenly distribute loads when use the product. Tipping and drowning may occur with uneven distribution of loads.

SAVE THESE INSTRUCTIONS

TECHNICAL SAFETY INSTRUCTIONS

Read the manual and follow the instructions. For your own safety, always heed the advice and warnings in these instructions. Only use the product in the places and conditions for which it is intended.

- Passenger numbers and load weight shall by no means exceed passenger number and maximum weight capacity in the specifications.
- This product should not be used as life saving device.
- Before every use, carefully inspect all product components, to ensure everything is in good condition and tightly secured.
- Be careful when landing on the ground. Sharp or rough objects (such as rocks, cement, shells, glass, etc.) may puncture the product.
NOTE: Drawing for illustration purposes only. May not reflect actual product. Not to scale.

MAINTENANCE AND STORAGE

1. After use, use a damp cloth to gently clean all surfaces.
NOTE: Never use solvents or other chemicals that may damage the product.
2. Store in a dry place, with a temperature higher than 15°C/59°F, out of reach of children.

IMPORTANT: If the product is damaged, discontinue use and discard it immediately as it cannot be repaired.