

**PHILIPS**



## Philips 5000 Series Sandwich Maker

HD2350/80

- Indicator lights show when it's ready to start
- Avoids mess with cut-and-seal plates
- Space-saving vertical storage
- Includes waffle and panini plates
- On/off switch for safety and control

## Make quick and easy sandwiches

Sandwich maker for toast, waffles & paninis

- 3 sets of plates for paninis, waffles, and sandwiches
- 750W of power toasts your sandwiches to perfection
- Removable non-stick plates for easy clean-up
- Even heating for perfect melting and toasting
- On/off switch for safety and control
- Compact vertical storage saves space in your kitchen
- Indicator lights display when it's ready to toast
- Built-in cord storage for a tidy countertop
- Easy Lock system snaps shut for a tight seal
- Cut-and-seal plates keep your fillings inside

Indicator lights show when it's ready to start, Avoids mess with cut-and-seal plates, Space-saving vertical storage, Includes waffle and panini plates, On/off switch for safety and control

HD2350/80

## Highlights

### 3 different plate sets



No more sandwiches sticking to plates or endless scrubbing. With our sandwich maker with removable plates, simply take them out and clean easily thanks to the long-lasting non-stick coating.

### 750 W of power



Rapid heating toasts everything to crisp, golden perfection in this powerful 750W sandwich toaster.

### Removable non-stick plates



No more sticking and scrubbing. Simple remove the plates and clean with ease thanks to the long-lasting non-stick coating.

### Even heating



Enjoy sandwiches just how you like them: melted, mouthwatering and perfectly golden brown all over.

### On/off switch



No need to unplug your sandwich press to turn it on and off.

### Compact vertical storage



The sandwich toaster stands vertically for convenient storage on your countertop or in the cupboard.

### Indicator lights



Lights clearly indicate when your panini maker is warming up and when it's ready to use.

### Built-in cord storage



Wrap the cord for orderly storage without cluttering your kitchen.

### Easy Lock system



Press sandwiches to perfection every time with a toastie maker that easily snaps open and closed.

Indicator lights show when it's ready to start, Avoids mess with cut-and-seal plates, Space-saving vertical storage, Includes waffle and panini plates, On/off switch for safety and control

HD2350/80

# Specifications

## General Specification

Cord length: 75 cm (exposed length)  
Interchangeable plates: Yes  
Product Type: Sandwich maker  
Power light: Yes  
Non-slip feet: Yes  
Integrated on/off switch: Yes  
Pre-programmed settings: No  
Functions: Bake  
Cord storage: Yes  
Capacity Water tank: N/A  
Primary Material: PF  
BPA free: Yes  
Warranty: 2 years

## Technical Specifications

Frequency: 50-60 Hz  
Voltage: 220-240 V  
Number in pack: 1  
Power: 750 W  
Battery Product: No

## Compatibility

Included Accessories 1: Waffle plates  
Included Accessories 2: Panini plates

## Safety feature

Automatic shut-off: No

## Weight and Dimensions

Product Length: 23.9 cm  
Product Width: 23.6 cm  
Product Height: 11 cm  
Product Weight: 2404 g  
Package Length: 18.3 cm  
Package Width: 26.3 cm  
Package Height: 29.4 cm  
Package Weight: 643 g

## Durability

Case: 100% recycled content  
User Manual: 85% recycled paper

## Country of Origin

Produced In: China



Publication Date  
2025-09-06  
Version: 54.54.1  
EAN: 8720389032820  
[www.phillips.com](http://www.phillips.com)

2025 © Versuni Holding B.V. All rights reserved.  
PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.