



TR-63

www.denver.eu

09/2024



FR

Cet appareil
est recyclable

À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCHÈTERIE



OU

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Keep product out of the reach of children and pets to avoid chewing and swallowing.
3. Never use old and new batteries or different types of batteries together. Remove the batteries when you are not using the system for a longer period of time. Check the polarity (+/-) of the batteries when inserting them in the product. Wrong positioning can cause an explosion. Batteries are not included.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Do not expose to heat, water, moisture, direct sunlight!
7. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
8. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
9. The direct plug-in cable is used as disconnect device, the disconnect device shall remain readily operable. So, make sure there is space around the power outlet for easy access.
10. Do not use non original accessories together with the product as this can make the product functionality abnormal

Power supply

Supply

It is necessary to power the device by connecting the power cord to the product. Connect the power cord to a 230 ~ / 50Hz electrical socket.

Warning!

The power cord may only be replaced by an authorized person in an authorized workshop. The device is under constant voltage when the power cord is plugged in, even if the device itself is turned off.

Control elements

1. Speaker
2. Telescopic antenna
3. AUX/FM/AM switch
4. Tuning scale
5. Tune
6. Adjust the volume (Volume)
7. with the power button Ventilation opening
8. Connecting the Power Cord (AC IN)
9. Connector for external input signal (AUX)
10. Battery Compartment (battery size 4 x AA not included)



Radio control

1. Connect the AC power cord (8) to a specified electrical socket.
2. Set the AUX / FM / AM switch (3) to FM or AM.
3. Turn the volume knob (6) to turn on the unit and adjust the volume.
4. Turn the tuning control (5) to tune to the desired station.
5. Turn the volume knob (6) to adjust the volume setting for the tuned station.

When listening to radio

Slide the telescopic antenna (2) to its maximum length, straighten it and adjust its direction so that FM station reception is as good as possible.

When receiving AM, a built-in ferrite antenna is used. For the best AM reception, turn the entire unit horizontally until reception is of the highest quality.

Turning off the device

Set the volume knob (6) to OFF.

Listening to an external audio source

1. Connect the AC power cord (8) to a specified electrical socket.
2. To the external input source (AUX) jack (9) connect the AUX cable (not included) as well as the output jack (etc. for headphones) on a portable audio player or mobile phone.
3. Set the AUX/FM/AM switch (3) to AUX.
4. Play music on the connected audio device.
5. Turn the volume knob (6) to turn on the unit and adjust the volume.

Turning off the device

Set the volume knob (6) to OFF.

Maintenance

Cleaning the surface of the device

Use a soft cloth slightly moistened with water to clean the surface of the device, panel, and controls. Do not use abrasive cloths, cleaning powders, or solvents such as thinner, benzine, or alcohol.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly. Electric and electronic equipment is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste, but should be disposed of separately.

All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type TR-63 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: denver.eu and then click the search ICON on topline of website. Write model number: TR-63. Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range::FM:87.5-108MHZ,AM:530-1600KHZ

Max Output Power:1X15W/1X1.5W RMS

DENVER A/S

Omega 5A, Soefte

DK-8382 Hinnerup

Denmark

www.facebook.com/denver.eu

Contact

Main contact point: contact.hq@denver.eu

Nordics

Headquarter
Denver A/S
Omega 5A, Soefthen
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**
(Push "1" for support)

E-Mail
For technical questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux

DENVER BENELUX B.V.
Barwoutswaarder 13C+D
3449 HE Woerden
The Netherlands

Phone: **0900-3437623**
E-Mail: **support.nl@denver.eu**

Spain/Portugal

DENVER SPAIN S.A
Ronda Augustes y Louis Lumiere, nº 23 – nave
16
Parque Tecnológico
46980 PATERNA
Valencia (Spain)

Spain
Phone: **+34 960 046 883**
Mail: **support.es@denver.eu**

Portugal:
Phone: **+35 1255 240 294**
E-Mail: **denver.service@satfiel.com**

Germany

Denver Germany GmbH Service
Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail
support.de@denver.eu

Fairfixx GmbH
Repair and service
Rudolf-Diesel-Str. 3 TOR 2
53859 Niederkassel

(for TV, E-Mobility/Hoverboards/Balanceboards,
Smartphones & Tablets)

Phone: **+49 851 379 369 69**
E-Mail: **denver@fairfixx.de**

Austria

Lurf Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3085**
E-Mail: **denver@lurfservice.at**

Poland

LetMeRepair Poland sp. z o.o.

ul. Częstochowska 140
62-800 Kalisz

Phone: **62 75 38 092**
E-Mail: **denver-service@letmerepair.pl**

Godziny pracy: 8 – 18 (poniedziałek – piątek)

If your country is not listed above,
please write an email to
support@denver.eu



Denver A/S
Omega 5A, Soefthen
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu