







Cordless Multifunctional Tool

TC-MG 18 Li-Solo

Item No.: 4465170

Ident No.: 11017

Bar Code: 4006825628593

The cordless multifunctional Einhell TC-MG 18 Li - Solo tool is a high-quality helper for extension, renovation and restoration jobs and is a member of the PXC family. The magnetic tool fixation with 12 adjustable settings enables the user to change accessories quickly and comfortable. The speed electronics allows the tool to be adapted to the particular material/application. The oscillation decoupled battery uptake with vibration reduction and the soft grip ensure comfortable operation. It comes with a triangular sanding plate, 9 sheets of abrasive paper (3*P60/3*P80/3*P120), scraper, plunge-cut saw blade for wood & plastic (HCS) as well as a segment saw blade additionally for soft metal (HSS). Supplied without battery and charger.

Features & Benefits

- Member of the Power X-Change family
- Comfortable accessory change thanks to magnetic tool fixation
- Speed electronics for material and application suitable working
- Oscillation decoupled battery uptake for reduction of vibration
- Safe and pleasant working thanks to soft grip
- 12-pin-tool fixation for flexible positioning of equipment
- Incl. triangular grinding/sanding plate
- Incl. 9x grinding/sanding paper (3*P60/3*P80/3*P120)
- Incl. scraper
- Incl. plunge-cut saw blade for wood and plastic (HCS)
- Incl. segment saw blade for wood, plastic and soft metal (HSS)
- Supplied without battery and charger (available separately)

Technical Data

- Oscillating speed 11000-20000 min^-1

- Angle of oscillation

- Sandpaper size 93 x 93 x 93 mm

Logistic Data

- Product weight 0.86 - Gross weight single packaging 0.86

75 x 165 x 257 mm - Dimensions single packaging

- Pieces per export carton 10 Pieces - Gross weight export carton 14 kg

- Dimensions export carton 530 x 405 x 190 mm - Container quantity (20"/40"/40"HC) 6620 | 13480 | 14400





















Available as special accessories

Dust Adapter TC-MG 18 Li Multifunctional Tool Accessory Item No.: 4465171 Bar Code: 4006825628609



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698

Einhell Accessory

18V 2,6Ah P-X-C Plus Battery Item No.: 4511436

Bar Code: 4006825616590

Einhell Accessory

18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437

Bar Code: 4006825616606 Einhell Accessory

Power-X-Twincharger 3 A Charger

Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376

Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 30min Power-X-Change Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory



Power-X-Boostcharger 6 A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350 Einhell Accessory