







Alienware 32 240 Hz-gamingmonitor
AW3226DM
Snabbstartsguide






* Inkluderade kablar varierar beroende på land






2






3




4













1





3



2







Dell.com/support/AW3226DM