













Dell Pro 34 Plus USB-C navbildskärm
P3425WE





*Endast i vissa länder









2





3























Dell Display and Peripheral Manager
Dell.com/support/ddpm



KVM



Dell.com/support/P3425WE