







Cordless Angle Grinder

TC-AG 18/115 Li - Solo

Item No.: 4431130

Ident No.: 11017

Bar Code: 4006825628746

The Einhell cordless angle grinder TC-AG 18 Li - Solo for sanding/cutting/polishing is the lightest angle grinder of its class. For safety there is a softstart function & restart safeguard. The overload cut-out, robust alu gear housing & modified air guidance contribute to a longer service life. For comfortable operation the motor and gearing are separated, resulting in very smooth operation; the tool is of slimline design with ergonomic soft grip surfaces. The handle can be fitted in three positions. It is also a member of the Power X-Change family: the same rechargeable battery for all PXC devices. For optimum results a 2.6 Ah Plus battery or higher is recommended. The battery, charger & cutting disc are available separately.

Features & Benefits

- -Member of the Power X-Change family
- -Lightest angle grinder of its class
- -Softstart function and restart safeguard to make it safer to use
- -Overload cut-out for a long service life
- -Modified air guidance for better cooling and longer service life
- -Very smooth operation thanks to separation of motor and gearing
- -Robust aluminium gear housing
- -Slimline design with ergonomic softgrip
- -Additional handle can be fitted flexibly in 3 positions
- -Recommendation for optimum results: 2.6 Ah Plus battery & higher
- -Supplied without battery and charger (available separately)
- -Supplied without cutting disk



- Size of grinding wheel cover 115 mm 8500 min^-1 - No-load speed (idle speed) Max. - Max. cutting depth 28 mm

Logistic Data

- Product weight (kg) 1.21 - Gross weight (kg) 2.05

290 x 142 x 108 mm - Dimensions single packaging

6 Pieces - Pieces per export carton - Gross weight of export carton 13.4 ka

- Dimensions Export Carton 440 x 310 x 252 mm - Container quantity (20"/40"/40"HC) 4914 | 10206 | 11340

















Available as special accessories



18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350 Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 Einhell Accessory



18V 30min Power-X-Change PXC-Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory



18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory