










Pro HD 24 PoE





1




2




3





4







5




6





7



If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

© 2020 Ubiquiti Inc. All rights reserved. Ubiquiti, the Ubiquiti logo and UFI are trademarks or registered trademarks of Ubiquiti Inc. in the United States and in other countries. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. Edge Router is a service mark of Apple Inc., registered in the U.S. and other countries. Android, Google Play, and the Google Play logo are trademarks of Google LLC.

