










Dell Pro 24 Justerbar stativbildskärm


E2425HSM









2





3






4
















1







2




3







Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/E2425HSM