





Cordless Drill

TC-CD 18/35 Li - Solo

Item No.: 4513927

Ident No.: 11018

Bar Code: 4006825642452 The Einhell TC-CD 18/35 Li - Solo cordless drill/screwdriver is a handy helper from the Power X-Change series of products. For exceptionally easy handling it has an ergonomic design and softgrip. Electronic speed control with 21 settings ensures that the tool is adjustable to the particular material

WER CHANGE

and application. The screwdriver has a 10 mm double-sleeve drill chuck. For optimum operation in dark areas there is LED lighting. The product is supplied in a practical storage box. The rechargeable battery and charger are available separately. The batteries with the high-grade lithium-ion cells

Features & Benefits

- A member of the Power X-Change family
- Speed electronics for material and application suitable working

can be combined with all members of the Power X-Change family.

- Always Ready-for-use due to Li-ion technology without discharging
- LED lighting for optimum operation in dark areas
- Extremely easy to work with due to ergonomic design and Softgrip
- Supplied in practical storage carton
- Battery and charger available seperatly

Technical Data

- Number of gears

- Idle speed (gear 1) 0-550 min^-1 - Max. torque hard 35 Nm - Number of torque steps 21 settings

- Drill chuck 10 mm | double sleeve

- Number of accumulators 0 Pieces

Logistic Data

- Product weight 0.97 - Gross weight single packaging 1.32 kg

- Dimensions single packaging 200 x 80 x 194 mm

- Pieces per export carton 4 Pieces - Gross weight export carton 6.5 kg

350 x 215 x 215 mm - Dimensions export carton

- Container quantity (20"/40"/40"HC) 6880 | 0 | 0















Available as special accessories



Bit-Set, 23-teilig Cordless Drill Accessory Item No.: 4258073 Bar Code: 4006825573268

Einhell Grey



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 **Einhell Accessory**



18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 **Einhell Accessory**



18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power-X-Twincharger 3 A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



Drill and bit set, 70 pcs Power Tools Accessory Item No.: 4258085 Bar Code: 4006825563610 Einhell Grey



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 30min Power X-Change Charger Item No.: 4512011 Bar Code: 4006825587029 **Einhell Accessory**



Power-X-Boostcharger 6 A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350 Einhell Accessory