







**Cordless Hedge Trimmer** 

GE-CH 36/65 Li-Solo

Item No.: 3410960

Ident No.: 11018

Bar Code: 4006825639018

The Einhell GE-CH 36/65 Li-Solo cordless hedge trimmer is a powerful tool which operates without a cable thanks to Power X-Change. The hedge trimmer for cutting through hedges, shrubs and bushes is powered by two 18 V PXC rechargeable batteries. The cutters are made of laser-cut and diamond-ground steel and just like the metal gear unit, are designed for a long life. The rotating handle and ergonomic, slimline front handle with microswitch make it comfortable to work with. The cordless hedge trimmer has an aluminium cover for the cutters. The product is supplied complete with a practical cuttings collector, impact guard with wall holder and a sturdy cutter guard for storage and transport. The battery and charger are available separately.

## Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Blades made of laser-cut and diamond-ground steel
- Swivel handle
- Ergonomic, small front handle with micro switches
- Metal gearing for a long life
- Cutting collector
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)

## **Technical Data**

- Blade length 720 mm - Cutting length 650 mm - Spacing between teeth 30 mm 2700 min^-1 - Cuts per minute

## **Logistic Data**


- Product weight 4 kg - Gross weight single packaging 5.3 kg

1180 x 231 x 200 mm - Dimensions single packaging

- Pieces per export carton 4 Pieces - Gross weight export carton 22.5 kg

1200 x 485 x 290 mm - Dimensions Export Carton - Container quantity (20"/40"/40"HC) 532 | 1176 | 1344



















## Available as special accessories



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 Einhell Accessory



18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power-X-Twincharger 3 A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 30min Power X-Change Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory



Power-X-Boostcharger 6 A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350 Einhell Accessory