







Cordless Rotary Hammer

TE-HD 18 Li-Solo

Item No.: 4513812

Ident No.: 11014

Bar Code: 4006825604054

The cordless drill hammer TE-HD 18 Li-Solo is a robust and versatile power house for screwing and drilling jobs with additional powerful hammer function and independence from mains. Thanks to its pneumatic hammer mechanism highly good propulsion in concrete is enabled. Due to its ergonomic handle with soft grip the drill can be handled comfortably and safely at every time. The practical quick stop function against unwanted coastdown of drills and the bright LED light for optimal illumination of the working area provide further operational comfort. ATTENTION: This device is delivered WITHOUT battery and charger.

Features & Benefits

- Member of the Power X-Change family
- 3 functions: screwing, drilling, hammer drilling even in concrete
- Pneumatic hammer action for easy drilling in concrete
- Powerful motor and metal gearing for high torque
- Universal SDS-plus-bit mounting with auto-slip-in function
- Finely adjustable speed electronics for sensitive jobs
- Ergonomic grip area with softgrip
- Incl. LED-light to illuminate working area
- Supplied without battery and charger (available separately)

Technical Data

- Idle speed (gear 1) 0-1100 min^-1 0-5700 min^-1 - Impact rate (gear 1) 1.2 J - Impact power - Max. torque hard 14 Nm - Drilling capacity in concrete 12 mm

Logistic Data

- Pieces per export carton 8 Pieces - Gross weight export carton 13 kg - Tool weight 1.39 kg - Gross Weight 1.58 kg

- Dimensions single packaging 266 x 80 x 215 mm 545 x 340 x 230 mm - Dimensions export carton - Container quantity (20"/40"/40"HC) 5216 | 10704 | 12264



















Available as special accessories



18V 2,0 Ah Power-X-Change

Battery Item No.: 4511395

Bar Code: 4006825610369

Einhell Accessory



18V 30min Power-X-Change Charger Item No.: 4512011

Bar Code: 4006825587029

Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681

Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power-X-Twincharger 3 A Charger Item No.: 4512069 Bar Code: 4006825629729

Einhell Accessory

18V 4,0 Ah Power-X-Change Battery Item No.: 4511396

Bar Code: 4006825610376 Einhell Accessory



18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350

Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698

Einhell Accessory



18V 2,6Ah P-X-C Plus Battery Item No.: 4511436

Bar Code: 4006825616590 Einhell Accessory



Power-X-Boostcharger 6 A

Charger

Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory