









Dell Pro 27 bildskärm
E2726H
Snabbstartsguide






*Medföljande kablar varierar mellan länder







2





3


















Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/E2726H