













Sensor may misdetect door slam noise as glass break.






Opened door may block sensor and reduce sound detection.

1









2






B










3



SuperLink Gateway




4







CR123A Battery



2x





If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

©2024 Ubiquiti Inc. All rights reserved. Ubiquiti, the Ubiquiti U logo, UniFi Protect, UniFi, and Superlink are trademarks or registered trademarks of Ubiquiti Inc. in the United States and other countries and/or regions. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries and/or regions. Apple Store is a service mark of Apple Inc., registered in the U.S. and other countries and/or regions. Android, Google, Google Play, the Google Play logo are trademarks of Google LLC.

