




HYPER 212 3DHP BLACK
HYPER 212 3DHP BLACK ARGB
MANUAL


01. PACKAGE CONTENT

A




x1

B




x1

C



x2

D




x2

E



x2

F




x1

02. INTEL & AMD


Intel - LGA 1851/1700/1200/115X: B,C,E

AMD - AM5/AM4: D,E


B



C





D




E








03. INTEL & AMD




04. INTEL & AMD





05. INTEL - LGA 1851/1700/1200/115X




06. INTEL - LGA 1851/1700/1200/115X




07. AMD - AM5/AM4




08. AMD - AM5/AM4



09. PWM CONNECTION



10. ARGB/PWM CONNECTION



Please visit our website at www.coolermaster.com

China - Cooler Master China

Room 112, Building 9, No. 327, Songjin Road, Jinshanwei Town, Jinshan Dist.,
Shanghai City, China
Tel: 400-9986-400

Europe - Cooler Master Europe B.V.

Lodewijkstraat 1b, 5652AC Eindhoven, The Netherlands
Tel: +31-(0)40-702-0900

North America - CMI USA, Inc.

1 N Indian Hill Blvd Suite 200, Claremont, CA 91711, USA
Tel: +1-888-624-5099

For the most updated information, please visit our official website: www.coolermaster.com
Cooler Master Support: <https://account.coolermaster.com/>

EC

REP

Cooler Master Europe B.V.
Lodewijkstraat 1b, 5652AC Eindhoven,
the Netherlands
consumer_care@coolermaster.eu



512007251-GP Ver 2.0 2025/06

©2025 Cooler Master Technology Inc. All Rights Reserved. All trademarks are registered to their respective owners.