

FloatBright™ Solar LED Pool Fountain Manual

OWNER’S MANUAL

WARNING

READ AND FOLLOW ALL INSTRUCTIONS
SAVE THESE INSTRUCTIONS

- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- It must only be supplied at SELV.
- This appliance shall not be used by children.
- Cleaning and User maintenance shall not be carried out by children.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Pumps without indication that they are protected against the effect of freezing shall not be left outside during freezing weather conditions.
- Children shall not play with the appliance.
- This appliance contains batteries that are non replaceable.
- If instructions is missed, please contact with Bestway or search it in website: www.bestwaycorp.com.
- This device complies with RSS-210 of Industry Canada.
- Operation is subject to the following two conditions:
 - (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.

DISPOSAL



Electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

PRODUCT SPECIFICATIONS

Light Modes:	9
LED Colors:	7
Battery Capacity:	18650 2000 mAh 3.7V
Working Current:	400 mA ± 20 mA
Ratings:	3,7 V  max. 2 W
Working Environment Temperature:	5°C (41°F) - 50°C (122°F)
Storage Environment Temperature:	-10°C (14°F) - 50°C (122°F)
Waterproof Rating:	IP67
Fountain Upward Distance:	50 cm (19.5")
Charging Time :	5 - 10 hours (depending on sunlight exposure)

Fountain and Top Light Maximum Working Time:

NOTE: This data is collected under sufficient sunlight exposure.


3 hours

NOTE: The user should allow the motor to cool for 15 seconds between every hour of use.

USAGE INSTRUCTION




- Press and hold the button for 3 seconds to turn on / off.
- Quickly press the button to change between the 9 light modes.



Fountain
Top Light
Bottom Light

- Please use the product in clean water.
- Place the product under the water as shown to discharge the remaining air.




- When powered on, the product will not work if there is too much ambient light. It will only work in the dark.
- When powered on, the fountain and the top light will turn on automatically when it is in the water. The two functions have an auto shut-off setting of 1 hour. To reactivate the two functions, take the product out of the water, press and hold the On/Off button to turn it off and back on, then place it back in the water.

IMPORTANT: When not in use, make sure to power off the product after removing it from the water.

- Drawings are for illustration purposes only. May not reflect actual product. Not to scale.

MAINTENANCE & STORAGE



- Use a brush to gently remove any stubborn debris around the two metal pins indicated in the illustration above if the fountain function does not work.
- Be sure the product is completely clean and dry before the storage. If all the parts are not completely dry, mold may result.
- Store in a cool, dry place and out of children's reach.