



Einhell

EXPERT PLUS



Cordl. Wet/Dry Vacuum Cleaner

TE-VC 36/30 Li S-Solo

Item No.: 2347140

Ident No.: 11018

Bar Code: 4006825635874

The Einhell TE-VC 36/30 Li S-Solo cordless wet and dry vacuum cleaner is a member of the Power X-Change series. For optimum use of the battery there are two speeds: ECO and BOOST. Both the 30 l stainless steel tank and the 36 mm stainless steel telescopic tube are robust in design. The accessory holder for neat storage, cable holder integrated in the housing and water drain screw make it a practical product to use. The blow connector is for blow-cleaning hard-to-reach areas. Easy transportation is ensured by the large castors and wheels. The product is supplied with a heavy-duty suction hose (Ø 36 mm, 2.5m) and a large combination nozzle for carpets and smooth flooring. The battery and charger are available separately.

Features & Benefits



- Member of the Power X-Change family, 2x18V batteries necessary
- 2 speeds (ECO/BOOST) for optimal battery use
- High suction power with simultaneous wireless freedom
- Stainless steel tank with 30 l capacity
- Blow connector for difficult corners
- 2 large wheels & 2 castors for better mobility
- Practical accessories holder for clean stowage and operations
- Practical cable holder for tidy stowage
- Water drain screw for draining the sucked water
- Telescopic stainless steel suction tube Ø 36 mm
- Incl. heavy-duty suction hose Ø 36 mm, 2.5 m
- Incl. big comfort nozzle for carpets/smooth floors
- Air regulator on the handle
- 1 foam filter for wet vacuuming, 1 pleated filter and 1 paper bag
- Supplied without battery and charger (available separately)

Technical Data

- Volume	30 L
- Suction power max.	150 mbar
- Suction hose length	2.5 m
- Suction hose diameter	36 mm
- Sound pressure level L _{pa}	76 dB (A)

Logistic Data

- Gross weight (kg)	11.71
- Pieces per export carton	1 Pieces
- Container quantity (20"/40"/40"HC)	222 456 608



Available as special accessories



Set Of Nozzles 2
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351255
Bar Code: 4006825635676
Einhell Accessory



Pleated Filter With Lid
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351113
Bar Code: 4006825566512
Einhell Accessory



Foam Filter 10 pcs.
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351130
Bar Code: 4006825236132
Einhell Accessory



Fabric Filter
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351140
Bar Code: 4006825231151
Einhell Accessory



Extension hose 36mm/3m
Wet/Dry Vacuum Cleaner Access.
Item No.: 2362000
Bar Code: 4006825543018
Einhell Accessory

Dirt Bag Filter 30l (5 pcs.)
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351170
Bar Code: 4006825528763
Einhell Accessory



5 pcs. Accessory Kit 64mm
Wet/Dry Vacuum Cleaner Access.
Item No.: 2362010
Bar Code: 4006825604290
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 30min Power X-Change
Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



Synthetic dust bag 40L (5 pcs)
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351195
Bar Code: 4006825625691
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power-X-Boostcharger 6 A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



Power-X-Twincharger 3 A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Round Carpet Brush
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351230
Bar Code: 4006825630091
Einhell Accessory



Soft Upholstery Brush
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351225
Bar Code: 4006825630084
Einhell Accessory



Set Of Nozzles 1
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351235
Bar Code: 4006825630107
Einhell Accessory



Car Cleaning Set
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351245
Bar Code: 4006825630121
Einhell Accessory



Long Crevice Nozzle
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351205
Bar Code: 4006825630046
Einhell Accessory



Small Universal Nozzle
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351210
Bar Code: 4006825630053
Einhell Accessory



Universal Floor Nozzle
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351215
Bar Code: 4006825630060
Einhell Accessory



Hard Upholstery Brush
Wet/Dry Vacuum Cleaner Access.
Item No.: 2351220
Bar Code: 4006825630077
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 1,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512021
Bar Code: 4006825601350
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory